

Sure-Foot Industries Corp.
20260 First Avenue
Cleveland, Ohio 44130
Phone: 800-522-6566
Fax: 440-234-9098
www.surefootcorp.com



Master Stop Tapes Installation Instructions

Installation Guidelines

- Testing of adhesive before installation is suggested
- Surface temperature must be above 55°
- Apply to smooth surface—repair application area by filling in any cracks or pits; seal porous surfaces; DO NOT apply over grout lines
- Clean surface using industrial cleaner—remove oils, dirt and flaking paint
- Flush surface to remove any soap residue
- Allow ample dry time
- Cut to size—rounding corners is suggested
- Peel off paper backing (keep fingers off adhesive)
- Position and press into place pushing from the center out to the edges to remove air bubbles (for enhanced bond, use rubber hand roller)
- Ready for immediate use
- Surface can be cleaned using mild floor cleaner as directed