




**Industrial
Products®**

PRIME DESIGN™


A Safe Fleet Brand




OTC Base Mounting System

Pages 2-3	Packaging Contents
Pages 4	FBM Mounting
Pages 5-6	Mounting to OTC Channels
Pages 7-8	Installing Mount Braces


FBM-1051




Base Mounting Leg..... (Qty 4)




Mounting Leg Connector Assembly (Qty 4)




Crossbar Mounting Brace..... (Qty 2)




Channel Mounting Brace..... (Qty 4)



HKT-0188 Crossbar Mounting Connector Hardware Kit



HKT-8061 FBM Hardware Kit




Anti-Seize (included Hardware Kits)



INSTALLING MOUNTING LEGS**8' BODY CONFIGURATIONS**


NOTE: Recommended installation distances are as shown.

*Ensure clearance for fastening hardware under the front and rear mounting surfaces of your truck box.

**9' BODY CONFIGURATIONS**


NOTE: Recommended installation distances are as shown.

*Ensure clearance for fastening hardware under the front and rear mounting surfaces of your truck box.


**11' BODY CONFIGURATIONS**

NOTE: Recommended installation distances are as shown.

*Ensure clearance for fastening hardware under the front and rear mounting surfaces of your truck box.


**1**

Install Mounting Hardware from HKT-8061 as shown..




INSTALLING MOUNTING LEGS

- 2.1** Install Mounting Leg Connectors onto the Base Mounting Legs as shown.






- 2.2** Re-install Mounting Leg Connector Hardware as shown.




MOUNTING TO OTC CHANNELS

NOTE: Channels and Crossbars in this Overview are shown for reference only. Specific configurations are determined by Service Body size, and Crossbar preferences.


**MOUNTING TO CHANNELS**

REAR MOUNTING FOOT NUT BRACKETS




- 4.1** Install one M8 Nut Bracket in each rear Mounting Foot channel as shown.

MID MOUNTING FOOT NUT BRACKETS





- 4.2** Install two M8 Nut Brackets in each mid Mounting Foot channel as shown.

MID CROSSBAR BRACE INSTALLATION




Anti-Seize
Must apply Anti-Seize
Compound and torque
to specified value.


- 5.2** Install the mid Crossbar Braces as shown. Do not torque until Step 5.3.




- 5.3** Install the mid Crossbar Brace Hardware into the top Nut Bracket as shown. Torque all Hardware to 90 in-lbs.




REAR/MID CROSSBAR-CHANNEL BRACE INSTALLATION



- 6.2** Install Braces into the inside of the Channels as shown.



- 6.3** Install the lower end of the Braces into the Mounting Foot channels using the remaining pre-installed Nut Brackets and Hardware as shown. Torque to 90 in-lbs.



USAM-FBM1051-US01 Rev-A 0220