

## Edge Angel SRL

Part #	Length	Description
10920	20'	3/16" Galvanized Cable SRL w/Shock Pack, Swivel Top, Snap Hook, Boot Cover, & Carabiner
10922	25'	3/16" Galvanized Cable SRL w/Shock Pack, Swivel Top, Snap Hook, Boot Cover, & Carabiner
10925	30'	3/16" Galvanized Cable SRL w/Shock Pack, Swivel Top, Snap Hook, Boot Cover, & Carabiner
10927	50'	3/16" Galvanized Cable SRL w/Shock Pack, Swivel Top, Snap Hook, Boot Cover, & Carabiner
10928	65'	3/16" Galvanized Cable SRL w/Shock Pack, Swivel Top, Snap Hook, Boot Cover, & Carabiner

Compliant with all OSHA 1910, OSHA 1926 Subpart M, ANSI Z359.14-12, and ANSI A10.32-2012 regulations.

Custom configurations available. Repairable by the manufacturer. Contact customer service for details.

Edge Angel SRL is suitable for the following applications:



**Personal Fall Arrest:** Edge Angel SRLs may be used in Personal Fall Arrest applications to support a MAXIMUM 1 Personal Fall Arrest System. Structure must withstand loads applied in the directions permitted by the system of at least 5,000 lbs. Maximum free fall is 2'. SRL may be positioned no more than 2' below harness dorsal D-ring. Applicable D-ring: Dorsal.



**Restraint:** Edge Angel SRLs may be used in Restraint applications. Restraint systems prevent workers from reaching the leading edge of a fall hazard. Always account for fully deployed length of SRL. Structure must withstand loads applied in the directions permitted by the system of at least 1,000 lbs. No vertical free fall is permitted. Restraint systems may only be used on surfaces with slopes up to 4/12 (vertical/horizontal). Applicable D-rings: Dorsal, Chest, Side, Shoulder.

### Class B SRL-LE

Average arrest force: 900 lbs.

Maximum arrest force: 1,800 lbs.

Maximum deceleration distance: 54".

Suitable for use in Leading Edge (LE) applications.

Setback distance: As determined by product testing, Guardian Fall Protection Edge Angel SRLs MUST be installed a MINIMUM 6' (1.8m) from the leading edge of applicable fall hazard(s).

Anchor point MUST NOT be lower than the leading edge of applicable fall hazard(s).

The allowable angle of redirection of the lifeline portion of Edge Angel SRLs at the leading edge of a fall hazard MUST be at least 90°.

Attach Edge Angel SRL carabiner to selected anchorage connector, and attach snap hook to applicable harness D-ring.

Prior to use, a Competent Person MUST calculate appropriate fall clearance.

