



## Inductive Head Poles Rodders



### Safe, Efficient Way To Test And Locate Out-Of-Reach Cables

Fiberglass foam-filled pole has Inductive Head Clamp Adapter permanently mounted to one end and male ferrule at the other end.

Use with Inductive Head Clamp in manholes or on poles. Access cables without climbing a pole or exhausting a manhole.

Foam core prevents moisture build-up inside pole and adds extra hoop strength and rigidity.



Inductive Head Clamp Pole  
Adapter Permanently Mounted On Pole



Removable Inductive Head Clamp Adapter  
Connects to Jameson Extension Pole

Part Number	Inductive Head Poles
FG-4MC	4' Inductive Head Pole
FG-6MC	6' Inductive Head Pole
FG-8MC	8' Inductive Head Pole
FG-10MC	10' Inductive Head Pole
IHA-2	Removable Inductive Head Clamp Adapter