

## QUICK GUIDE TO INSTALL ONE-TOUCH STAIRWAY

1. Place stairway frame in rough opening in a "free state" abutting the ceiling. Mark all 8 lag screw holes.
2. Bring the stairway down a little and pre-drill all 8 holes with a 5/16th bit.
3. Replace the stairway frame in rough opening and insert lag screws on the long side of frame (2 on each side) and stop torquing when the lag screw "kisses" the frame.
4. Slide the sections to their fully retracted position then connect the quick releases to eyebolt on each side of the tow bar.
5. Remove the tie wraps which are locking the pivoting panel to the frame.
6. Connect the power and bring the stairway fully down with the toggle switch.
7. When the stairway is fully extended place a wood support under the last sliding section of the stairway so that it is resting on it prior to climbing on One-Touch stairway.
8. Put the 4 remaining lag screws in the short sides (2 each). Stop torquing when the lag screws head is "kissing" the aluminum frame.
9. Disconnect the wire twists from the toggle switch and run the electric cable through the wall to where the toggle switch is to be installed. Then, reconnect all wires via the wire twists to the toggle switch wires (color to color)
10. Put on shoes as described in the instruction manual.